

SECTION 07 14 16
FLUID APPLIED WATERPROOFING (SOLVENT BASED)
PAVERS OVER MORTAR BED OVER WOOD SUBSTRATE (WITH DRAINAGE MAT)

PART 1 GENERAL

1.1 SECTION INCLUDES

- A. Fluid applied flexible rubber based waterproofing system for Pavers over Mortar Bed over Wood Substrate (with Drainage Mat).

1.2 RELATED SECTIONS

- A. Section 07 60 00 Flashing and Sheet Metal
- B. Section 07 62 00 Sheet Metal Flashing and Trim
- C. Section 07 76 16 Roof Decking Pavers
- D. Section 06 10 00 Rough Carpentry

1.3 REFERENCES

- A. ASTM D412 Test Method for Tensile Properties of Plastics.
- B. ASTM D1204 Test Method for Linear Dimensional changes of Non-rigid Thermoplastic Sheet or Film at Elevated Temperature.
- C. ASTM G26 Practice for Operating Light Exposure Apparatus (Xenon Arc Type) With and Without Water for Exposure of Non Metallic Surfaces.
- D. ASTM E96 Water Vapor Transmission of Materials.
- E. ASTM E108 Test Methods for Fire Test of Roof Coverings.
- F. FM 4470 Wind Uplift Resistance.

1.4 SUBMITTALS

- A. Shop Drawings:
 - 1. Indicate special joint or termination conditions and conditions of interface with other materials.
- B. Product Data:
 - 1. Provide data for rigid insulation material.
 - 2. Provide data for material description, physical properties, recommended storage conditions, shelf life, precautions, flexible flashings, and joint and crack sealants, with temperature range for application of waterproofing membrane.
 - 3. Manufacturer's Installation Instructions: Indicate special procedures and perimeter conditions requiring special attention.
 - 4. Manufacturer's Certificate: Certify that products meet or exceed specified requirements.
 - 5. Test data: Provide documentation supporting tests referred to under item 1.3.

1.5 QUALIFICATIONS

- A. Applicator: Company specializing in performing the work of this section approved by manufacturer.
- B. Manufacturer shall have been in business and shall have had experience in manufacturing these products for a minimum of 15 years.

1.6 REGULATORY REQUIREMENTS

- A. CT Products are Naphtha based and are **HIGHLY FLAMMABLE!**
- B. CT Products **MUST** be **POURED** out of the bucket then applied. **DO NOT** plunge roller into bucket, as static electricity from the roller may start a fire.

1.7 DELIVERY, STORAGE, AND HANDLING

- A. Deliver materials to site in manufacturer's unopened and undamaged containers bearing the following information:
 - 1. Name of manufacturer
 - 2. Name of contents and products code
 - 3. Net volume of contents
 - 4. Lot or batch number
 - 5. Storage temperature limits

- C. Metal Primer:
Sealoflex Metal Etch Primer™ Corrosion resistant acrylic primer for ferrous metal
- D. Adhesive Sealant:
Generic Single-part polyurethane caulk
- E. Drainage Mat:
Sealoflex Sealodrain 650™ Drainage mat and protection board which allows water to flow to designed exits

PART 3 EXECUTION

3.1 EXAMINATION

- A. Verify substrate surfaces are durable, free of frozen matter, dampness, loose particles, cracks, pits, projections, or foreign matter detrimental to adhesion or application of waterproofing system.
- B. Verify that substrate surfaces are smooth, and not detrimental to full contact bond of waterproofing materials.
- C. Verify that deck surface has positive drainage.

3.2 PREPARATION

- A. Protect adjacent surfaces not designated to receive waterproofing.
- B. Clean and prepare surfaces to receive waterproofing by removing all loose and flaking particles, grease and laitance.
- C. Do not apply waterproofing to surfaces unacceptable to manufacturer.
- D. Seal cracks and joints with sealant materials using depth to width ratio as recommended by sealant manufacturer.

3.3 APPLICATION

- A. Apply Surface primer(s), if applicable, depending upon surface conditions. Allow to dry.
- B. Apply Accessory primer (s), as necessary. Allow to dry.
- C. Apply 3/8" triangular bead of Adhesive Sealant at internal corners.
- D. Apply Base Coat, Flashing Fabric and Saturation Coat over board joints, cracks, flashings and non-working joints and perimeter, at 30 sq.ft. per gallon. Allow to dry.
- E. Optional: install primed metal drip edge at perimeter, adhering into place with Adhesive Sealant.
- F. Apply Base Coat, Field Fabric and Saturation Coat at 30 sq. ft. per gallon over the entire area. Overlap adjacent runs of fabric 3" minimum. Allow to dry.
- G. Apply two coats of Finish Coat over the entire area at 140 sq. ft. per gallon per coat. Allow to dry between coats.
- H. Waterproofing system should be a minimum of 40 mils total cured thickness.
- I. Allow waterproofing system to cure 7 days.
- J. Install Drainage Mat over the entire area and secure in place with waterproof tape.
- K. Install Mortar Bed and Pavers as designed by engineer.

3.4 CLEANING

- A. Clean unscheduled surfaces receiving waterproofing in accordance with manufacturer's instructions.

3.5 PROTECTION OF FINISHED WORK

- A. Protect finished waterproofing from inclement weather until cured.

END OF SECTION

IMPORTANT NOTE: Always check our website, www.sealoflex.com to determine if the printed literature you are reading is the most current version available.