



**INSTRUCTIONS FOR BLISTER REPAIR ON CONCRETE
USING DAMPSEAL 101™ REPAIR KIT**

Dampseal 101™ Repair Kit:

1. Dampseal 101™ Component A
2. Dampseal 101™ Component B
3. 60 ML Syringe
4. Plastic Needle
5. 16 Gauge Steel Needle
6. Mixing Stick
7. Disposable Gloves
8. Dampseal 101™ MSDS
9. Instruction Sheet

Additional Items you will need:

1. Concrete blocks
2. Wax paper
3. Wallpaper roller
4. Rags
5. Water

Procedure:

1. Puncture all blisters in three locations, (12:00, 4:00, 8:00) with the either needle
2. Mix Dampseal 101™ Component A with Component B
3. Fill the syringe with the mixture
4. Inject the blister from all three locations
5. Using the wallpaper roller, roll the blister until it is flat
6. Using a damp rag, clean off any excess material that has squeezed out of puncture holes
7. Place a piece of wax paper over the blister
8. Place the concrete block over the wax paper
9. Wait 30 – 45 minutes and remove the block and wax paper